

Instructions Firstwheels

CITY ELITE & TRACK ELITE & TWIN ELITE

**IMPORTANT MESSAGE: Read these instructions carefully before use.
Not following these instructions correctly may endanger your child.**

Never leave your child unattended in the stroller and always ensure supervision by an adult. Before use, always check if the bolts are locked and the cot, seat or adaptor with car seat, have been secured correctly. When you are using the stroller seat, always fasten your child in the 5-point safety belt, even when using the foot bag. For safety, we advise against running or skating behind the stroller.

Do not use the cot for babies heavier than 9 kilograms. The seat is designed for children with a maximum weight of 15 kilograms. When using the adaptor with a car seat, keep to the maximum weight indicated on the car seat. It is not advised to use the seat for children younger than 6 months. The seat is only safe to use when the child is able to sit unaided. Once your child is able to sit unaided, it is not advised to make use of the cot. Always keep an eye on your child and out of the way of the moving parts, when you are (un)folding the stroller. Pay attention that your child does not climb into the stroller on its own. Always put the brakes on when you are not moving; the brakes are activated by pushing the pedal in between the back wheels down, and is released by pulling the same pedal up. Always keep hold of the stroller when it is standing at an angle, even when the brakes are on. For extra safety always use the wristband. Never use the stroller on stairs or escalators, as your child may fall out. The stroller may topple when hung onto or when heavy bags are hung onto it. Check everything regularly and only use accessories and parts, allowed by the manufacturer. All Firstwheels strollers had been approved according to: BS EN 1888:2003.

Maintenance



Clean the fabric with lukewarm water and soap. Rinse with fresh water and leave to dry. Never use a bleach or chemical detergents. Periodically grease the wheels and metal parts to ensure the stroller keeps running smoothly. Rinse the wheels if necessary, for example after a day at the beach, to remove the salt.

Warranty

A 12-month warranty period commences on the day of purchase. Warranty is given on manufacturing faults, only on presentation of the original receipt of purchase. In the event of defects, you should contact your dealer. If the dealer cannot deal with the complaint, he will contact the manufacturer. Repairs do not entitle to an extension of the warranty period.

No warranty is given in the event:

- The product is returned without the original receipt of purchase
- Defects / damages were caused by improper use or by changes made by the consumer
- Discolouring/circles occur, caused by washing, rain or sun
- Wear and tear occurs, which can be expected to be the result of normal use

Accessories included

Sun hood - a baby is very sensitive to direct sunlight, so never leave your baby unprotected in the sun.

Mosquito net - (only with the carry cot) keeps mosquitoes and other insects away from your child. Attach it over the hood and at the foot end of the cot.

Rain cover - The cover protects your child against the rain. Attach it over the hood and at the foot end of the seat. The cover is fitted with ventilation holes; nevertheless do not leave your child under the rain cover when it is not raining, as heat will develop under the cover.

Optional accessories

Parasol, foot bag, sleeping bag, adaptor for various car seat brands, nursing backpack, nursing shoulder bag, pump, transportation bag for stroller.

CITY ELITE

Unfolding the stroller illustration 1-3

The under-carriage is fitted with a safety pin for transportation. You need to unbolt it, by turning the pin down. Turn the under-carriage upside down and unfold the stroller. Ensure that the plastic plates, left and right, click firmly into place. The height of the push bar is adjustable by pushing the adjustment handles, left and right, at the same time, allowing you to lower or heighten the bar.

Wheels illustration 4

Take the two big wheels and place them on the axle, making sure you simultaneously press the spring down. Check the wheels are secure and check the tyres for pressure. If necessary, fill the tyres with air. The maximum tire pressure is 28PSI (2.0 bar).

Brake illustration 5 - 6

Pushing the lever, in between the back wheels, down activates the brake. To release the brake, pull the same lever up again with your foot.

Stroller seat illustration 7

Make sure that the connecting piece of the seat fits exactly on the adaptor of the under-carriage and that it clicks firmly into place. The seat may be placed facing the front or the back.

Sun hood illustration 8

When you are using the hood, pay attention that the plastic components of the hood, fall exactly into those of the seat. Make sure they click firmly into place.

5-point safety belt illustration 9 - (10-1)

Put the brake on, when putting your child in the seat. Use the elastics at both sides of the seat to fasten the shoulder straps temporarily. This is for putting your child more easily in the seat. Fasten the shoulder straps to the hip belt, always double check if the seatbelts are fastened. The back may be adjusted to three different settings by loosening or tightening the buckle attached at the back of the stroller.

To prevent your child falling forward and injuring itself we strongly recommend you attach the Velcro strap at the back of the seat to the upper tube of the seat when the seat is in the upright position.

Use of carry cot (optional) illustration 11 - 17

Put the sides of the travel cot in a vertical position. Turn the plastic components on both the sides, downwards. Pull at the loop on the bottom of the cot, until you hear it click. Place the cot on the under-carriage and push downwards at the right point, until it clicks into place. Also push at foot end to click into place. To dismantle the cot, you pull the lever under the cot towards you, uncoupling the cot. By simultaneously pressing the plastic knobs at the side, the cot may be lifted from the under-carriage.

Taking the stroller apart illustration 19 - 20

Slide both the adjustment handles of the push bar down at the same time and push the push bar right down to the ground. Remove the seat and the hood from the under- carriage. Turn the safety pin towards you and fold the under-carriage. Ensure the safety pin clicks firmly into place.

TRACK ELITE

Unfolding illustration 1- 3

The under-carriage is fitted with a safety pin for transportation. You need to unbolt it, by pulling it down. Pull the push bar up with both hands, until the bolts click on both sides of the frame. Lock both the clips on the frame. The height of the push bar is adjustable by pushing the adjustment handles, left and right, at the same time, allowing you to lower or heighten the bar.

Wheels illustration 4 - 6

The front wheel is secured by a click mechanism. You secure the front wheel by clicking the clip into the notch. Before placing the back wheels you need to remove the safety pins (2x) from the undercarriage. Subsequently you place the wheels on the undercarriage, push the safety pins back and click the lever of each pin to lock. Check if the wheels are secure and check the pressure of the tyres. If necessary, fill the tyres with air. The maximum pressure is 28 PSI (2.0) bar. To block the swivel hub function you have to click the ring of the front wheel into the opening in the frame.

Brake illustration 7 - 8

Pushing the lever, in between the back wheels, down activates the brake. To release the brake, pull the same lever up again with your foot.

Stroller seat illustration 9 - 11

The sun hood may be removed by pushing the clip on each side inwards. Unfasten the seating at both sides; by unfasten the poppers at the bottom and top (total 8). Unfasten the straps at the back by pulling the straps through the tiny opening in the ring. Slide the seating forwards, off the frame. Beware; the straps at the back are also the fastenings of the 5-points safety belt. Ensure therefore that these are fastened securely at all times.

5-points safety belt illustration 12 - 13

Put the brake on, when putting your child in the seat. Use the elastics at both sides of the seat to

fasten the shoulder straps temporarily. This is for putting your child more easily in the seat. Fasten the shoulder straps to the hip belt, always double check if the seatbelts are fastened. The back may be adjusted to three different settings by loosening or tightening the buckle attached at the back of the stroller.

To prevent your child falling forward and injuring itself we strongly recommend you attach the Velcro strap at the back of the seat to the upper tube of the seat when the seat is in the upright position.

Use of carry cot illustration 14 - 20

Put the sides of the travel cot in a vertical position. Turn the plastic components on both the sides, downwards. Pull at the loop on the bottom of the cot, until you hear it click. Place the cot on the under-carriage in the right position and push at foot end until it clicks into place. To use the sun hood, you click the plastic components, left and right, into place. To dismantle the cot, you pull the lever under the cot towards you, uncoupling the cot and slide the cot away from the under-carriage.

Folding illustration 21

Unfasten the clip at each side (1), then pull the fastening at the top towards you (2). Push the push bar down (3).

TWIN ELITE

Unfolding illustration 1 - 3

The under-carriage is fitted with a safety pin for transportation. You need to unbolt it, by pulling it down. Pull the push bar up with both hands, until the bolts click on both sides of the frame. Lock both the clips on the frame. The height of the push bar is adjustable by pushing the adjustment handles, left and right, at the same time, allowing you to lower or heighten the bar.

Wheels illustration 4 - 6

The front wheel is secured by a click mechanism. You secure the front wheel by clicking the clip into the notch. Before placing the back wheels you need to remove the safety pins (2x) from the undercarriage. Subsequently you place the wheels on the undercarriage, push the safety pins back and click the lever of each pin to lock. Check if the wheels are secure and check the pressure of the tyres. If necessary, fill the tyres with air. The maximum pressure is 28 PSI (2.0) bar. To block the swivel hub function you have to click the ring of the front wheel into the opening in the frame.

Brake illustration 7 - 8

Pushing the lever, in between the back wheels, down activates the brake. To release the brake, pull the same lever up again with your foot.

Stroller seat illustration 9 -11

The sun hood may be removed by pushing the clip on each side inwards. Unfasten the seating at both sides; by unfasten the poppers at the bottom and top (total 8). Unfasten the straps at the back by pulling the straps through the tiny opening in the ring. Slide the seating forwards, off the frame. Beware; the straps at the back are also the fastenings of the 5-points safety belt. Ensure therefore that these are fastened securely at all times.

5-points safety belt illustration 12 - 13

Put the brake on, when putting your child in the seat. Use the elastics at both sides of the seat to fasten the shoulder straps temporarily. This is for putting your child more easily in the seat. Fasten the shoulder straps to the hip belt, always double check if the seatbelts are fastened. The back may be adjusted to three different settings by loosening or tightening the buckle attached at the back of the stroller.

To prevent your child falling forward and injuring itself we strongly recommend you attach the Velcro strap at the back of the seat to the upper tube of the seat when the seat is in the upright position.

Use of carry cot illustration 14 - 20

Put the sides of the travel cot in a vertical position. Turn the plastic components on both the sides, downwards. Pull at the loop on the bottom of the cot, until you hear it click. Place the cot on the under-carriage in the right position and push at foot end until it clicks into place. To use the sun hood, you click the plastic components, left and right, into place. To dismantle the cot, you pull the lever under the cot towards you, uncoupling the cot and slide the cot away from the under-carriage.

Folding illustration 21

Unfasten the clip at each side (1), then pull the fastening at the top towards you (2). Push the push bar down (3).

